

# Analog Peak Detector and Derandomizer

G. De Geronimo, A. Kandasamy, P. O'Connor


Brookhaven National Laboratory

IEEE Nuclear Sciences Symposium, San Diego

November 7, 2001


# Multichannel Readout Alternatives

## Direct digitization




- most flexible
- requires many fast ADCs
- expensive, high power

## Track-and-Hold + Analog Multiplex




- requires trigger
- has deadtime
- timing uncertainty
- requires sparsification

## Analog Memory + Analog Multiplex



- requires trigger
- can be deadtimeless (complex control)
- requires sparsification


# Ideal Self-triggered, Self-sparsifying, Deadtimeless Readout



# Peak Detector (PD)

## Advantages

- self-triggering
- self-sparsifying
- timing output




## Drawbacks

- accuracy impaired by op-amp offsets, CMRR, slew rate
- poor drive capability
- deadtime until reset

# Improved CMOS PD Using Two-Phase Configuration


## Write phase

- conventional peak detector
- M1: unidirectional current source
- voltage on  $C_H$  includes op-amp errors (offset, CMRR)



## Read phase


- same op-amp re-used as unity-gain buffer
- same CM voltage
- **op-amp errors cancel**
- enables rail-to-rail sensing
- provides good drive capability




# Two-Phase Peak Detector in 0.35 $\mu\text{m}$ CMOS

*SCHEMATIC*



PD loop with switches



Switch control logic (*data driven*)




*LAYOUT*




# Two-Phase CMOS Peak Detector - Results


## Waveforms




## Absolute accuracy



## Droop rate



## Time walk



# Two-Phase CMOS Peak Detector - Summary


- Self-triggering
- 2-phase operation eliminates op-amp errors
  - *High absolute accuracy independent of process, supply, temperature variation*
  - *Rail-to-rail input and output*
- Strong drive capability
- No switch charge injection into hold node
- Timing output

<b><i>Parameter</i></b>	<b><i>Value</i></b>
Technology	0.35 $\mu$ m CMOS DP4M
Supply voltage	3.3 V
Input voltage range	0.3 – 3 V
Absolute accuracy	0.2 %, $t_p \geq 500$ ns 0.7%, $t_p = 200$ ns
Time walk	$\pm 2.3$ ns, $V_{in} < 2.5$ V $\pm 5$ ns, $V_{in} < 3$ V
Droop rate	0.25 V/s
Power dissipation	3.5 mW
Cell area	0.03 mm <sup>2</sup>




# Peak Detector and Derandomizer


- Combine the peak detect and analog hold functions of the PD with additional analog storage and control logic to create a Peak Detector–Derandomizer (PDD).
- PDD behaves like a data driven, analog FIFO memory.
- Topologies:




*A: Array of PD with ping-pong control*



*B: PD plus SCA as analog buffer*




*C: PD with multiple hold capacitors*



Topology A with two parallel PDs has been fabricated and tested.

# Multichannel Readout System with PDD




SSM: self-switched multiplexer; custom chip that detects above-threshold inputs and routes them to PDD input.

In response to a **READ** request from the DAQ system (pulser), the next peak sample stored in the PDD is presented to the 12-bit ADC.


After a fixed delay the pulser **RESETs** the PDD that was read out, freeing it to process next input pulse.

# Multichannel PDD Readout System: First Results



- Input pulses from source occur randomly
- READ process is synchronous 200 kHz
- READ rate matches average input rate
- Simultaneous readout and acquisition of new data
- 2-sample buffer absorbs rate fluctuations

# Multichannel PDD Readout System




## Spectra

Solid line: commercial MCA.

Points: PDD, single channel.

Circles: PDD, 16 channels gain-adjusted.

Resolution limited by CZT detectors.



## Source Profile

$^{241}\text{Am}$  source centered over channel 2.

# Summary

- New 2-phase peak detector in submicron CMOS:
  - *High absolute accuracy (0.2%) and linearity (0.05%)*
  - *Rail-to-rail input and output*
  - *$\pm 2.3$  ns time walk*
  - *Low power (3.5 mW)*
  - *Extremely compact (0.03 mm<sup>2</sup>)*
- A building block for compact, efficient multichannel readout system:
  - *Self-triggered*
  - *Self-sparsifying*
  - *Deadtimeless*
- Peak detector – derandomizer (PDD) with 2-event buffer demonstrated:
  - *First step towards data-driven analog FIFO readout*